

FT 2+2 DAYLIGHT SAVINGS

1000 SERIES

MAIN MENU,
SET PARAMETERS ENTER 4 DIGIT CODE.
IF NO CODE PROGRAMMED IN USE DEFAULT 0000

GO TO TIME AND STORE HOURS
1ST ONE ON SUB MENU. ENTER
YOU WILL BE ON TOP OF THIS PAGE IN FRONT OF THE HOUR

HIT ENTER SELECT 1 TIME. THIS WILL PUT YOU ON THE HOUR.
USE +/- TO CHANGE THE HOUR. ARROW OVER TO MINUTES AND CORRECT
THEM IF NECESSARY.
THEN ENTER SELECT 3 MORE TIMES TO LOCK IN THE TIME CHANGE.

IF YOU DON'T HIT 3 TIMES
AFTER 1 MINUTE THE TIME WILL REVERT BACK TO ORIGINAL TIME
BEFORE YOU CHANGED IT.

MAIN MENU
OUT TO FIRST SCREEN (MENU, GREET, WINDOW, TOTAL.)
DONE,
GOOD JOB!!