

HME 6000 IQ REGISTRATION

Upon receiving your unit, it must first be registered with the Base Station in your store.

1. Place battery in unit. Do not turn on unit.
2. Open Base Station by depressing clips at the top.
3. Press the "start registration" button in the lower left hand corner. You should see an "O" on the LED display.
4. Hold the "B" button on the belt pack as you turn on then let go. It will take only a few seconds and the light on your belt pack should turn green.
5. Unit is ready for use.



R.F. TECHNOLOGIES, INC.

542 South Prairie Street
Bethalto, IL 62010

Office: 618.377.2654 Fax: 618.377.1320

Visit us online at www.rftechno.com