

HME SYSTEM 30 TIMER DAYLIGHT SAVING TIME ADJUSTMENT

1. Press the "Set Up System" key on the keypad.



The set up system menus display will appear.

Press the EXIT key anytime you want to stop.

Set Up System Menus:
SYSTEM SETUP

Press + or - & ENTER

2. If SYSTEM SETUP is not flashing on the display, press the + or - key until SYSTEM SETUP is flashing, then press the ENTER key.

The system setup display will appear.

3. If SET DATE & TIME is not flashing on the system setup display, press the + or - key until SET DATE & TIME is flashing, then press the ENTER key. DATE/TIME display will appear.

System Setup:
SET DATE & TIME

Press + or - & ENTER

4.

| |
|-------------------|
| Date/Time |
| Date: MAR 08, 07 |
| Time: 07:57A |
| Daylight Sav: YES |

 - When a month is flashing, press the + or - key if you want to change the month, then press the ENTER key.