

HME SYSTEM 30 TIMER DAYLIGHT SAVING TIME ADJUSTMENT

1. Press the "Set Up System" key on the keypad.



The set up system menus display will appear.

Press the EXIT key anytime you want to stop.

Set Up System Menus:
SYSTEM SETUP

Press + or - & ENTER

2. If SYSTEM SETUP is not flashing on the display, press the + or - key until SYSTEM SETUP is flashing, then press the ENTER key.

The system setup display will appear.

3. If SET DATE & TIME is not flashing on the system setup display, press the + or - key until SET DATE & TIME is flashing, then press the ENTER key. DATE/TIME display will appear.

System Setup:
SET DATE & TIME

Press + or - & ENTER

4.

Date/Time
Date: MAR 08, 07
Time: 07:57A
Daylight Sav: YES

 - When a month is flashing, press the + or - key if you want to change the month, then press the ENTER key.

SYS30 DAYLIGHT SAVINGS

USE THE SYSTEM KEY ON KEYPAD.

SET UP SYSTEM (NEXT TO THE ENTER BUTTON)

USE THE PLUS KEY TO FIND YHE WORD SYSTEM

ENTER.

USE PLUS KEY TO LOCATE TIME AND DATE.

USE THE NUMBER KEYS TO ENTER IN THE CORRECT TIME AND DATE.

USE +/- TO CHANGE THE AM TO PM

DAYLIGHT SAVINGS SHOULD BE DISABLED.

WHEN FINISHED HIT EXIT OUT TO MAIN SCREEN

YOUR DONE, GOOD JOB!!!